



M4A1 CARBINE

AIRGUN

4,5MM STEEL BB (.177) CO2

INSTRUCTION MANUAL




About the instruction

- This instruction is written for the purpose of using our product properly and safely. The instruction with illustrations enable users to understand and operate the product better. Properly use this product after you read it carefully and know all the notices in it.
- Warning: If you don't pay attention to the cautions and install or use it wrongly, it may cause accidents or malfunctions.
- We shall not be responsible for any damage or malfunction of the gun caused by wrongful operation stated in the instruction.



Please read it carefully before and after installation.

■ Contents



**HIGH POWERED FULL METAL
TRAINING GUN**

1 Component Names




2 Selector and Safety Setting (Always set the safety lever to SAFE before firing.)




CAUTION

Set the selector in position correctly; otherwise, malfunction may occur.




Selector




It can be operated even with one hand.

Left side





Right Side





SAFETY Setting The trigger cannot be pulled.

When you are not firing the gun or during storage, Always set the selector to the Safe position.



SEMI AUTOMATIC (Single Shot)

Pulled the trigger, the gun will fire one shot each time.



AUTO SHOOTING MARK(single shot)

Note: Due to technology limitation, it is single shot even put the switch on auto (mark).

The pointing direction is fix on the right side, its for decoration only.

WARNING · CAUTION

- Never operate the selector while pulling the trigger. Otherwise, malfunctions are possible, resulting in accidents.
- Pulling the trigger with the Selector being set to safe may damage the gun.

3 Setting the magazine

● Installation


Make sure to set the magazine upwards and connect it firmly until a click sound is heard.



CAUTION Confirm that the safety lever is set to the safety position and don't place your finger on the trigger.

● Removing the magazine

Press the magazine release to remove the magazine. (Support the magazine as it may drop.) **After Operation** (Refer to 14P)



Magazine catch lever

WARNING · CAUTION

- Always use the steel BBs Bullet for this air gun.
We shall not be held responsible for any damage or accidents arising from the use of bullets supplied by other manufacturers.


4 Setting the cartridge and fill the magazine with steel BBs (1)

- 1 Push on the release and remove the internal. Remove the magazine core as shown on picture.




press here


Remove the magazine core



- 2 Loose the screw to introduce the cartridge. Insert the cartridge and first, take care to perfectly center it at the top.




Anticlockwise the screw to proper position to insert the cartridge.



Put the cartridge in center



Setting the cartridge and fill the magazine with steel BBs (2)

- ③ Tight the screw. When pressure starts increasing in the compartment (expansion of the CO_2 in the compartment can be heard), finishing screwing rapidly.



CAUTION Do not tighten excessively, it could permanently damage the O-rings.


- ④ Please keep the spring on this position. Fill the magazine with 4.5mm steel BBs, max capacity is 18 pcs.




CAUTION

If the steel BBs get stuck and stop somewhere, upright the magazine to let the BBs fall down.

- ⑤ Screw the button to the position shown on picture, then insert the cartridge into magazine shell.



If necessary, press on the button.



Push the magazine core in place, until the release button lock the magazine shell.


5 Setting the Open Sight

Front Sight Setting the bullet hitting point.
Cover the front sight with the adjustment tool and turn.

Turning
counterclockwise:
Lowers the bullet
hitting point.

Calibrating tools

Turning clockwise:
Raises the bullet
hitting point.




WARNING-CAUTION

- Be sure not to lose the adjustment tool.
- The front sight will come off if turned too much.


Rear Sight 1 For left-right adjustment.

Turning the windage adjustment dial will move the bullet hitting point to the left or right.

Wind force adjustments
(right and left)




Turning clockwise:
Raises the bullet
hitting point.



Turning
counterclockwise:
Lowers the bullet
hitting point.

Rear Sight 2. For precision targeting.

The sight assembly is marked in millimeters for easy use.




WARNING-CAUTION

- **CARBINE** rear sight is designed as close to the real thing as possible. But, of course, the ranging will differ from the actual

Rear Sight 3. For up-down adjustment.


Turning the windage adjustment dial will move the bullet hitting point to the left or right.





Using the Carrying Handle and install sight

WARNING · CAUTION

- Make sure the Interface Knob on the Carrying Handle is secured to ensure it can't drop off the gun.




- Scopes can be attached to the Mount rail.




- Removal One-point

Put the fixed right side in place first on an angle before pushing down on the left side.



6 Movable Parts

- Pulling the charging handle opens the port cover.




WARNING · CAUTION

- When closing the port cover, make sure the charging handle has returned fully into position, otherwise the port cover will not close.



Simulated bullet Make sure it is clear






- Forward assist knob can be pushed.

- Trigger guard can be opened and closed (Used when you wear gloves in winter) Open with a pin like object.

Retractable Stock

WARNING.CAUTION

- Please follow the instruction on the demonstration chart.




7

FIRING (confirm safety sufficiently before beginning firing)

CAUTION Load the magazine charging the bullets, referring to "3.4 Setting the magazine"



- 1 Make sure to set the magazine upwards and connect it firmly until a click sound is heard.



- 2 Set the selector lever to Semi or Full Auto.

CAUTION ● Make sure to attach the protective plug to the gun muzzle, except when you are shooting, for preventing accidental, sudden discharge and for the dust-proof purpose. (Never pull the trigger with the protective plug being attached.)

● Activating the trigger carelessly is extremely dangerous. Never put your finger onto the trigger unless the protective plug is removed and you are ready to shoot a target.




Read it before you shoot.

CAUTION ● Never aim the gun at people or animals.

CAUTION ● Never shoot in the place where there are crowded people and heavy traffic or something explosive and flammable.

CAUTION ● Shooters must pay attention to the surrounding environment and put on goggles while do the shooting

- 4 Pull the trigger.



CAUTION

● Activating the trigger carelessly is extremely dangerous. Never put your finger onto the trigger unless put the selector on safe.

● A blank firing may occur at triggering after setting the magazine, this is the normal operation of the gun.

WARNING · CAUTION

- There are possible cases that no firing occurs after pulling the trigger in the semi auto mode.


8

Normal Disassembly for Overhaul (Take down) and Maintenance Procedures

CAUTION After removing the magazine, Fire the rifle in semi-automatic once to move the piston forward for easy disassembly.


③ Set the selector to SAFE place.

② Dry fire the gun in semi-auto mode.



① Remove the magazine.


① Push in Take down pin as far as it will go pivot Upper receiver from lower receiver.



② The barrel can be removed
Stop here for barrel cleaning

WARNING Do not disassembly push this point

CAUTION Do not pull the charging handle or the dummy bolt while disassembled. Doing so will damage the gun.



WARNING · CAUTION

- Attach or detach the upper receiver with the magazine being removed, Otherwise, bullets remaining in the magazine may jump out in to the receiver, causing malfunctions.
- After removing the magazine, Fire the rifle in semi-automatic once to move the piston forward for easy disassembly. After firing the single shot,

DEFENSE FORCES



Generalvertrieb:

MWM Gillmann GmbH
Adam-Berg-Str. 103 A
81735 München
Germany

www.russ-guns-de.net